

Instructions for Use (IFU)

Hand-Held Metal Detector Cleaning, Disinfection, and Sterilization

The following manufacturer's Instructions for Use (IFU) are permitted for the cleaning, disinfection, and sterilization of Garrett hand-held metal detectors.

1. Approved cleaning and disinfecting process for hand-held metal detectors:
 - Wiping is recommended over spraying liquids.
 - Wiping around labels on the product is acceptable.
 - Excessive wiping around labels should be avoided.
 - Take precautions when cleaning near the battery compartment, speaker, seams, screws, or switch area.
2. Compatible disinfectant types:
 - Ethyl alcohol, as in hand sanitizer and hand sanitizer wipes
3. Approved EPA-registered hospital disinfectant wipe:
 - [Sani-Cloth® AF3 Germicidal Disposable Wipe | PDI Healthcare](#)
4. Disinfectants and chemicals that should **not** be used:
 - No bleach or isopropyl alcohol
5. Precautions related to the battery compartment, speaker, seams, screws, or switch area:
 - Take precautions when cleaning near the battery compartment, speaker, seams, screws, or switch area.
6. Can Garrett hand-held metal detectors be sprayed, immersed, or only wiped?
 - It is safe to wipe the product with soap and water. Wiping is recommended over spraying liquids. Do **not** submerge or use running water.