GARRETT

UPDATE GUIDES ELEVATE YOUR GARRETT DETECTOR TO THE NEXT LEVEL

SOFTWARE UPDATE PROCEDURE

To update your Garrett detector, a PC computer running with Windows 7 or newer operating system and Mac OS 10.13 and higher is required.

You need to be connected to the Internet to perform your install.

Note: You must be a registered user on the garrett.com/store/ website to access any updates.

Register Here for Free Garrett Updates





- Login to garrett.com/store/ updates-support/ and download the update installer
- Locate and install the "GarrettInstaller.exe" (for PC) or "Garrettinstaller.dmg" (for Mac) download on your computer





- Run the Garrett updater application
- Login to your account
- **Connect** your device and launch scan
- If an update is available for your device follow the instructions and continue to step 3





UPDATES

- **Click** the "Upgrade to Latest" button
- Confirm your device is adequately charged (at least two bars)
- Once your install has successfully **completed**, a success notification will appear, you can then disconnect the USB cable and enjoy the update benefits

- PC or Mac (with Windows 7 OSX 10.13 or newer)
- Equipment An active Internet link
- Required: Garrett detector
 - Micro-USB or USB-C connection cable, depending on detector.

Note On Some Browsers:

J

Some virus protection programs could create a warning box that states running this app might put your PC at risk. Near the "Don't Run" box, there should be an option for "More Info." Click on this and select "Run Anyway" to complete installation.

0



